# **OPTOTRONIC<sup>®</sup> OT 60/220-240/12 P**


Constant Voltage LED Power supply for 12V LED - Modules

## 1. Technical Data


Nominal Voltage	220 – 240 Vac
Input Voltage	198 – 264 Vac
Line Current, nominal	0,32A@230 Vac
Mains Frequency	50 / 60 Hz
Power Factor	= 0.98 @ 230 Vac
Interface	None
IP Rating	IP 67
Max Out Power	60 Watt

Output Voltage	12,5 Vdc (- 0,5V/+0,5V)
Efficiency	87% @ 230 Vac
Ambient Temperature Ta	-25℃ to +55℃
Max. Case Temperature at Tc	+80℃
Max. Cable Length	10m
Max load per circuit breaker B10	11
Max load per circuit breaker B16	17
Max load per circuit breaker C10	17


## 2. Connection Schemes



# 3. Safety



Power supplies can be connected in parallel on the primary side, but not on the secondary side



The installation of two or more OPTOTRONIC® OT 60/220-240/12 P Power supplies with common "-" or "+" wiring is forbidden.



OSRAM AG www.osram.com

Steinerne Furt 62, 86167 Augsburg, Germany



# **OPTOTRONIC<sup>®</sup> OT 60/220-240/12 P**

Constant Voltage LED Power supply for 12V LED - Modules

# Wiring and Connection

- Ensure that the LED module load is within the range of rated voltage, current and power supply (see Technical data)
- Maximum output cable length is limited by EMI and cross diameter
- Use output cable sections adequate to the load demand
- The luminaire manufacturer is responsible for providing the required clearances and creepage distances and also for protection against electrical shock, especially for the line and load wires
- Please avoid direct exposure of sunlight and in case of exposure to UV rays, protect the cables with suitable silicone sheath.

### **Earth Connection**

OT 60/12 P is a "Protection Class II" power supply, therefore ground connection is not required


## Mounting and Environmental protection

- The control gear is a build in type for luminaire integration
- Maximum permissible ambient temperature must not be exceeded. Make sure there is adequate space to avoid a build-up of heat. In critical installations the temperature at t<sub>c</sub> has to be controlled

### 2 General Note

- Power supplies must be installed by a qualified electrician
- Disconnected from mains supplies before wiring work
- For further information see also "OPTOTRONIC Technical guide" at <u>www.osram.com</u>







AA390770055



